


TOP OFF FUNCTIONS

(ROCV™ FUNCTION ON REVERSE)


S1 & S2 Modes

In S1 & S2 Modes, one sensor is installed in the sump and one sensor is installed in the top off bin



S3 Mode


In S3 Mode, both sensors are installed in the sump



ROCv™ FUNCTION

(TOP OFF FUNCTIONS ON REVERSE)

For use with the ROCv™, both sensors are installed in the Top Off Bin



**Note: For Top Off or ROCv™ Functions,
Always Plug the Sensor with the
Red Wire into the Red Wire of the Y-Adapter,
and the Sensor with Two Black Wires
Into the Black Wire of the Y-Adapter**